

Your phone




Your Cellhire phone has been quality checked and tested and both batteries are fully charged.


1. Power key
2. Volume keys
3. Selection keys (pressing these keys will select the function displayed on the screen above the key (E.g. Menu))
4. 4-way-scroll key (enables scrolling through names, etc)
5. Dial / answer call key
6. Exit menu / end call key
7. Enter numbers and characters

Inserting / changing the SIM card


(If you have ordered your phone with airtime, your SIM will already be inserted in the phone.)




Remove the back cover from the phone. With the back of the phone facing you, push the back cover release button and slide the back cover off. Then remove the battery by lifting it up with the finger grip.



To release the SIM card holder, gently pull the locking clip of the card holder and open it outwards.



Insert the SIM card into the SIM card holder, ensuring that the gold contact areas on the SIM and phone are touching.



Close the SIM card holder and press until it snaps into position, insert the battery and slide the cover back into place.



To power phone on / off



Press and hold the button at the top of the phone until the phone powers on.


Repeat to switch off.

Keypad lock

Press  and then  (within 1.5 seconds.)


Repeat to unlock.

Set the time

In standby mode, press  then scroll to and select SETTINGS, TIME AND DATE SETTINGS and CLOCK.


Select SET THE TIME and enter the current time in 24 hour format and press OK.

Set the date

In standby mode, press  and select SETTINGS, TIME AND DATE SETTINGS and DATE.

Select SET THE DATE and enter today's date using the keypad and press OK.

Charging the battery





Connect the lead from the charger to the socket at the bottom of your phone, then connect the charger to a wall socket.

You may need to use a plug adaptor for the wall socket relevant to the country you are in. This is included in your rental pack. Charging can take up to 1 hour 30 minutes in standby mode.

You can use the phone while the charger is connected.

Answering / ending calls

To answer a call, press 

To end a call, press 

Making calls

To make an emergency call

Dial 112 

To redial the last number called

Press  


To make a domestic call

Dial CITY/AREA CODE then PHONE NUMBER and press  to send the call.

E.g. Domestic call within France dial: 01 41 43 79 40.

To make an international call

Press   within 1.5 seconds (+ sign will appear).


Dial COUNTRY CODE then CITY/AREA CODE then PHONE NUMBER and press  to send call.

(COUNTRY CODES are listed overleaf. The CITY/AREA code of most countries outside of North America begins with 0. This 0 should be omitted when dialling.)


E.g. International call to the UK, dial: +44 207 123 1234

Phone book

Saving contacts

In standby mode, press  then select PHONE BOOK and ADD NAME. Key in the contact's name and press OK. Key in the contact's phone number and press OK. When the name and number are saved, press DONE.

Searching for / calling a contact


In standby mode, press  then select PHONE BOOK and SEARCH. You can key in the first characters of the contact you are searching for in the pop-up window. Use the scroll key to scroll through the contacts in the list.

Press DETAILS to view the number of the selected contact.

To call the contact press 


Speed dials

Assigning a number to a speed dialling key

In standby mode press  and select PHONE BOOK and SPEED DIALS and scroll to the speed dialling key that you want to use.

Press ASSIGN press SEARCH and select the contact name and number you want to assign.


Speed dialling a phone number

Press the speed dialling key you want to call followed by 

Or press and hold the speed dialling key until the call has started.

Text Messages (SMS)

Creating an SMS

In standby mode press  and select MESSAGES, TEXT MESSAGES and CREATE MESSAGE

Key in the message using your key pad.


To send the message, press OPTIONS and select SEND and enter the recipient's phone number or SEARCH for the phone number in the phone book.

Press OK to send.

Reading / replying to an SMS

When you have received an SMS, an envelope signal followed by MESSAGE RECEIVED will be shown on the screen.

Press SHOW to view the message or press EXIT to view it later. Reading the message later:


Press  and select MESSAGES, TEXT MESSAGES and INBOX.

Scroll to the message you want to read and press SELECT.



To reply, press REPLY then select EMPTY SCREEN and enter your message.


Press SEND to send the message.

Retrieving your VoiceMail messages in France

Dial 8 8 8 and press 

Outside of France

Press   within 1.5 seconds (+ sign will appear).

Then dial 33 60 80 8. Dial the third, fourth, fifth and sixth digits of your mobile phone number then press . Enter the full mobile number and press #. Confirm your mobile number by pressing 1. If you make a mistake, press 2, re-enter the number followed by # and press 1 to confirm that it is correct. Enter your PIN code (0000) and press #.

Retrieval of messages left in your VoiceMail will be charged at the standard call rate. Please refer to your Rental Agreement.

Additional Information

For further information please visit www.cellhire.fr and click Assistance Clientèle.

International country codes

Australia	61
Austria	43
Belgium	32
Brazil	55
Canada	1
China	86
Finland	358
France	33
Germany	49
Greece	30
Hong Kong	852
Italy	39
Japan	81
Netherlands	31
Norway	47
Portugal	351
Russia	7
South Africa	27
Spain	34
Sweden	46
Switzerland	41
Taiwan	886
UK	44
US	1

Cellhire has pre-arranged procedures to collect your equipment, simply follow the instructions below.

Procedure 1 (within France and Monaco):

Step 1: Clearly fill in the sender's section of the CHRONOPOST airway bill, then date and sign the bottom right-hand corner of the form.

Step 2: Please ensure the phone and equipment are packed in the bubble wrap provided and are placed in the Cellhire bag. Failure to do so will make you liable for any damages caused in transit.

Step 3: Please stick the airway bill to the phone pack.

Option 1: Deposit the bag at the nearest post office desk (not the mail box). Please note that French post offices are closed on Saturday afternoons and Sundays. Please keep the receipt which will be given to you in return as it will be required as proof of delivery.

Option 2: Deposit the bag at your hotel reception desk or Concierge and ask them to post it for you. Please inform Cellhire by telephone if you wish to use this option. Please note that the phone is the customer's responsibility until it is received by Cellhire. The rental period will continue until the date of postage (option 1) or until you inform Cellhire by telephone that you wish to use option 2.

Procedure 2 (within rest of the EU):

Step 1: Place the equipment in the bubble-wrap, insert into the return bag and seal.

Step 2: Fill out section 1 of the attached UPS waybill with your name, address and phone number, (be sure to retain the top copy for your records). Cellhire is not able to track packages without a copy of the UPS waybill or tracking number.

Step 3: Call UPS in the country you are in (see list below) to arrange collection. Inform UPS that you have a prepaid return airway bill. Delivery and collection will take place in the same country.

Step 4: Hand the package to the UPS representative. If you are staying in a hotel, leave the package with the hotel concierge or reception desk. Make sure you take the name of the hotel representative for future reference.

UPS contact numbers (Please call UPS in the country that you will be returning your equipment from)

Austria	0810 006630	Italy	800 877 877
Belgium	0800 12828	Luxembourg	800 225 10
Denmark	8030 2222	Netherlands	0800 099 1300
Finland	0800 1 877 877	Portugal	707 23 23 23
France	0800 877 877	Spain	902 88 88 20
Germany	0800 8826630	Sweden	020 788 799
Greece	210 998 4000	Switzerland	0800 55 88 33
Ireland	1 800 57 57 57	UK	08457 877 877

Lost / stolen equipment

If your equipment is lost or stolen you must call Cellhire immediately on: + 1 214 355 5200. All calls made are the responsibility of the customer until the theft / loss is reported to Cellhire.

24 Hour Global Support

In France: 0810 610 610
International: +33 1 41 43 79 40

For on-line support, please visit www.cellhire.fr and click Assistance Clientèle.

Thank you for renting from Cellhire.